PARTS PRICE LIST

40-45 HP

HARRIS GASOLINE ENGINES

EFFECTIVE MAY 1, 1921


(SUBJECT TO CHANGE WITHOUT NOTICE)



THE HARRIS MANUFACTURING COMPANY

EXECUTIVE OFFICE AND FACTORY STOCKTON, CALIFORNIA

Branch Office and Factory
WALLA WALLA, WASHINGTON



PARTS PRICE LIST

40-45 HP

HARRIS GASOLINE ENGINES

EFFECTIVE MAY 1, 1921

(SUBJECT TO CHANGE WITHOUT NOTICE)



THE HARRIS MANUFACTURING COMPANY

EXECUTIVE OFFICE AND FACTORY STOCKTON, CALIFORNIA

Branch Office and Factory
WALLA WALLA, WASHINGTON

INSTRUCTIONS FOR ORDERING EXTRAS

Place your orders as far in advance of harvest as possible.

Place all orders with our authorized dealer in your territory.

Order all parts by LETTER, if possible.

If need for parts is urgent, order by TELEGRAPH. Telephone orders are taken at purchaser's risk as to delays and all transportation charges.

Give number and full description of parts, as well as size of machine for which wanted. Only our castings and motor parts are numbered. Therefore, give measurements as well as full description when ordering parts for Drapers, Straw Carriers Grain Carriers, Jackson Feeders, Separator Shoes, Screens, Shafting, etc.

Give your postoffice address, shipping point, county and state. Indicate whether shipment is wanted by express, freight or parcel post.

Consider the time of less-than-carload freight shipments before ordering parts be freight.

Express and freight shipments will be made charges collect unless there is no freight or express agent at your shipping point, in which case charges will be prepaid and added to charge for parts.


On all shipments by parcel post, postage will be added to charge for parts.


Shipments are not insured unless requested. (We will gladly insure parcel post-shipments on request, adding the cost to our charge.)


A packing list is included in each shipment of repairs. When received, compare the parts with this list and in case of shortage make report AT ONCE. Unless this is done, claims cannot be allowed.


No parts furnished free except in accordance with machine warranty.


Except where the responsibility is ours, a handling charge of 10 per cent of our charge for parts returned will be made in allowing credit.














PARTS LIST

HARRIS 40-45 HP TYPE "C" MOTOR

Part No.	Description	P	rice
M— 17	Governor Housing	3	75
M— 18	Governor Head		50
M— 19	Governor Slide	1	95
M— 22	Governor Ball		75
M— 23 M— 24	Governor Lever Eccentric	1	25
M— 24	Governor Adjusting Nut		35
M— 51	Center Door Clamp		25
AM— 51	Crooked Center Door Clamp		35
M— 60	Friction Drive Plate	9	75
M— 61	Friction Spreader Collar	8	25
M— 62 M— 63	Friction Cone	7	75
M-63	Friction Dogs		90
M— 64	Friction Links (3/8"x1"x2\frac{3}{16}")		10
M— 65	Bolt for M-61 Collar, with Nuts		25
M— 66	Pins for Collar, M-61 (Short)		25
M— 67	Magneto Shaft Coupling Flange	1	
M— 69	Cone Collar for Friction (2 Pieces)	7	
M— 70	Bolt for M-69 Cone Collar		15
M— 71 M— 72	Clutch Spring		75
M— 72 M— 82	Pin for Collar M-61 (Long)		15
M— 82 M— 84	Governor Spring		40
M— 84 M— 93	Piston for Oil Pump	1	
M— 95 M— 96	Stud for Governor Eccentric		50
M— 97	Collar for Magneto Shaft		95
M— 98	Pin for Cone Collar		20
M— 99	Spring for Oil Pump		25
M—103	Oiler Pulley		35 75
M—116	Clamp for Fibre Tube		20
M—118	Magneto Counting (Center Piece)	1	25
M—121	Magneto Coupling (Center Piece) Pin for Governor Balls (½"x1½"")	1	25
M—122	Flange for Water Manifold	1	10
BM-133	Bushing for Friction Pulley (Bronze)	20	00
M-201	Bushing for Friction Pulley (Bronze)	22	25
M-203	Cylinder	38	00
M204	Crankcase	181	50
M-205	Crankshaft Bearing (Center)	3	65
M-206	Crankshaft Bearing Cap (Center)	3	25
M—207	Piston	19	00
BM-207	Piston Bushings, per pair	5	00
M-209	Exhaust Manifold	8	85
M-210	Crankshaft Bearing (Gear End)	4	50
M—211	Crankshaft Bearing Cap (Gear End)	4	35
M—212	Crankshaft Bearing (Clutch End)	5	75
M—213	Crankshaft Bearing Cap (Clutch End)	9	35
M-214	Gear Case, with bushing.	18	
BM-214	Gear Case Bushing	1	85
M—215 M—216	Gear Case Cover		50
M 221	Magneto Gear Cover	3	65
M—221 M—225	Governor Arm	2	15
M—225 M—226	Pump Eccentric and Exhaust Cam	2	00
M—227	Exhaust Cam		75
M—228	Camshaft Bearing (Center)	1	75.
BM—228	Camshaft Rushing	5	00
M—229	Camshaft Bushing	2	
M—230	Camshaft Gear	10	75
M-231	Water Manifold (Outlet)		90
	(U	10

Part No.	Description	P	rice
M—232	Water Manifold (Inlet)		25
M—233	Rocker Arm		50
M—234 M—235	Rocker Arm Bracket		75
M—235 M—237	Cap for Magneto Bracket		40
M—238	Flywheel	72	00
M-239	Valve Guide	1	95
M-240	Tappet Guide		50
M—241 M—243	Tappet	. 1	80
M—245	Crankcase Door	6	00
M-246	Pump Body		25
M-247	Oil Distributor	10	90
M-248	Oil Distributor Cap		75 30
M—249 M—250	Clamp for Manifolds		45
M—252	Clamp for Door—End.		20
M—253	Camshaft Bearing (Clutch End)	4	65
M-268	Connecting Rod Bolt (Lower End), with Nuts	2	85
M—273 M—275	Piston Pin	5	50
M—275 M—276	Pin for Push Rod Head		15
M—277	Push Rod		60
M-278	Dust Cap		50
M-280	Valve Spring Washer		50
M—281	Valve Spring Washer Stirrup		35 20
M—283 M—285	Pump Rod	1	
M—287	Crankshaft	155	00
M-288	Connecting Rod, with Cap	12	30
3.5 000	Connecting Rod M-288, Comp. with bearings, bolts, etc.	18	50
M—289	Cap Screw for Connecting Rod (Upper End)	3	65
M—290 M—291	ValveCrankshaft Gear		
M—292	Magneto Shaft Gear.	6	70
M-295	Priming Cup Lever		65
M-301	Camshaft (Shaft only)	5	
M-302	Splash PanThrottle Rod		70 35
M-306 M-308	Gasket—Cylinder Head		
M-309	Gasket—Manifold		35
M-311	Gasket—Inlet Water Manifold		10
M-312	Gasket-Outlet Water Manifold		15 70
M—313 M—314	Exhaust Valve Spring		60
M—314 M—315	Connecting Rod Bearings, per pair.	4	
M-316	Oil Pipe 1/4"x16" with Cap		55
M-317	Oil Pipe, ¼"x6¾", with Cap Oil Pipe, ¼"x12½", with Cap		40
M—318 M—319	Oil Pipe, ¼"x12½", with Cap		50
M-319 M-320	Oil Pipe, ¼"x4", with Cap		25
M—324	Oiler Pulley on Camshaft	3	00
M-325	Elbow for Water Manifold	1	25
M = 326	Bracket for Oiler		35
M-327	Outboard Bearing Frame	29	15
M—328 M—329	Back Driver and Quill	27	50
M = 332	Pulley—Pump Drive	6	35
M = 333	Pulley—Pump Drive	60	00
M = 334	Quadrant for Governor Control		75
M—335	Lever for M-334 Quadrant		70 65
M—336 M—337	Lever—Magneto Advance		95
M—339	Bracket for KW Model HK or RK Magneto	7	25
M - 340	Intake Manifold	11	50
M-341	Exhaust Manifold	8	85
M—342 M—343	Bracket for Bosch ZR-4 Magneto Handle for M-335 Lever	0	60 65
M—343 M—344	Manifold Adapter for 1½" Ensign Carburetor	2	00

Part No.	Description	Price
M-345	Stud for Inlet Water Manifold, 3/8"x23/8"	
M - 346	Stud for Outlet Water Manifold, 3/8"x3"	15
M-347	Stud for Cylinder Head (Long), 5/8"x63/4"	35
M-348	Stud for Cylinder Head and Manifolds, 5/8"x6"	35
M-349	Stud for Quill, 7/8"x13"	90
M-420	Governor Shifting Yoke	95
M-456	Shim for Gear End Crankshaft Bearing, per doz.	40
M-505	Speeder Rod, 1/4"x81/2"	30
M-516	Stud for Tube Clamp, 1/4"x11/2"	08
M-517	Shim for Clutch End Crankshaft Bearing, per doz.	
M-522	Shim for Center Crankshaft Bearings, per doz.	
M-525	Stud for Inside Main Bearings, 5/8"x6"	30
M-526	Stud for Door (Center), ½"x23/8"	15
M-527	Stud for Door (Corner), ½"x2½"	13
M-528	Stud for Door (Bottom Center), 1/2"x23/4"	1.

MISCELLANEOUS PARTS 40-45 H.P. HARRIS MOTOR

Description	Price
Ball and Socket Joint (¼"x¼")	20
Ball and Socket Joint (¼"x½")	211
Brass Nipples—½"	15
Brass Elbows—1/8"	20
Carburetors (Write for I	rices)
Clarifiers, each	16 50
Cloths—Clarifier, each	1 00
Clutch Lever	7 70
Exhaust Pipes, each	4 50
Felt—¼", per pound.	4 45 50
Fibre Tubing—78", per foot.	200
Magnetos—KW Model RK (Write for I	30 00
Oilers—Manzel Force Feed, 4-feed.	20
Oilers—"Gits," 1/8" Shank	
Priming Cups—Fig. 368	
Friming Cups—Fig. 300	3 00
Sight-Feed Oil Cups—Fig. 33	4 25
Spark Plugs—Splitdorf Heavy Duty, each	1 25
Spark Arresters, Comp., 1237 bottom, each	7 50
Spark Plug Wrench	1 00
Starting Bar	1 00
Starting Bar	15
Stoves—Hot-air for Carburetors	12 75
Tana Dia No 4 2"	06
Taper Pins—No. 5, 1½"	. 06
Taper Pins—No. 2, 1½"	. 05
Taper Pins—No. 5, 1½" Taper Pins—No. 2, 1½" Taper Pins—No. 1, 1"	03
Vacuum Tanks—Stewart	12 50
Wire-Magneto, per foot.	15
Wire Terminals, each	. 05
Woodruff Key No. 5	05

